



## VH Stoelverwarmer “Vulcano”

Gefeliciteerd met de aanschaf van de VH Stoelverwarmer “Vulcano”.

De VH stoelverwarmer is speciaal ontworpen om een gelijkmatige en zeer comfortabele warmte af te geven. De stoelverwarmer kan op iedere stoel of bank worden gebruikt. Op kantoor, thuis of in serre. Deze instelbare stoelverwarmer is uitgerust met een LCD controller. Hiermee kan de maximale temperatuur op 8 standen worden gezet en een timer worden geactiveerd.

De stoelverwarmer is bedoeld om aangename warmte te bieden aan personen.

### Specificaties

- Stoelverwarmer
- Kleur: Abrikoos of Zwart
- Werkt direct op 230 Volt, voorzien van aan/uitschakelaar, 8 standen regeling en automatische timer
- Kabellengte: 3 meter. *1 meter tot de controller, 2 meter tot aan de stekker*
- Antislip onderzijde
- Voorzien van oververhittingsbeveiliging
- Voorzien van 8 standen. Maximale temperatuur\*:
  - o Stand 1-3: 33-43 °C
  - o Stand 4-6: 45-55 °C
  - o Stand 7-8: 60-65 °C

*\*De gerealiseerde temperatuur is afhankelijk van de omgevingstemperatuur.*

### Afmetingen en vermogen

Leverbaar in twee afmetingen:

| Artikelcode | Afmeting    | Maximaal vermogen | Gemiddeld verbruik | Kleur    |
|-------------|-------------|-------------------|--------------------|----------|
| VH-SV101    | 40 x 120 cm | 100 Watt          | 55 Watt            | Zwart    |
| VH-SV102    |             |                   |                    | Abrikoos |

### Toepassing

- De stoelverwarmer is geschikt voor toepassing binnenshuis.
- De stoelverwarmer is geschikt voor toepassing in droge ruimtes.
- De stoelverwarmer is geschikt voor toepassing op niet warmte gevoelige oppervlaktes. Let op bij toepassing op PVC of vinyl.
- De stoelverwarmer is niet geschikt voor gebruik op onbehandeld hout (zoals bijvoorbeeld underlayment). Bij gebruik op dergelijke onbehandelde oppervlaktes kunnen vlekken ontstaan.



## Gebruiksaanwijzingen

---

- Niet gebruiken in natte / vochtige ruimtes of buiten omgevingen.
- De stoelverwarmer niet afdekken om overbelasting en oververhitting te voorkomen.
- Gebruik de stoelverwarmer enkel op een droge en vlakke ondergrond.
- De stoelverwarmer niet buigen, niet doorboren, niet insnijden.
- Zorg dat de aansluitkabel en aanverwante onderdelen en componenten niet beschadigen.
- In geval van schade aan de kabel, schakelaar of de stoelverwarmer, direct de stekker uit het stopcontact nemen, neem eventueel contact op met uw leverancier.
- Dit apparaat mag niet worden gebruikt door personen (inclusief kinderen) met een verminderd fysiek, zintuiglijk of mentaal vermogen, of met onvoldoende ervaring en kennis, tenzij ze toestemming of instructies met betrekking tot het gebruik van het apparaat hebben gekregen van een persoon die verantwoordelijk is voor hun veiligheid.

## Belangrijke veiligheidsinformatie

---

- Schakel altijd de stroom volledig af wanneer u de elektrische onderdelen hanteert, bij installatie, verwijderen, schoonmaken of onderhoud.
- Lees alle informatie in deze handleiding nauwkeurig door.
- Gebruik de stoelverwarmer enkel zoals beschreven in de handleiding.

## Garantie

---

Alleen bij juiste plaatsing en gebruik volgens deze voorschriften kunnen wij u de volledige garantie geven. De VH Vulcano Stoelverwarmer is een onderhoudsvrij verwarmingssysteem met een garantie van 2 jaar op de elektrotechnische werking van de stoelverwarmer.

## Onderhoud en reiniging

---

De stoelverwarmer kan met de hand of in de wasmachine worden schoongemaakt.

- Zet de stoelverwarmer uit en haal de stekker uit het stopcontact.
- Verwijder het aansluitsnoer van de stoelverwarming bij het aansluitblok.
- Was de stoelverwarming met de hand of in de machine op maximaal 30 °C op een programma voor fijne was. Gebruik een mild wasmiddel.  
*Let op: Niet strijken, niet in de droger, niet bleken of stomen.*
- Zorg ervoor dat de het snoer en de stekker niet met water in contact komen!



## Bediening van de stoelverwarmer

---

### Temperatuurstellingen

- Schakel de stoelverwarmer in door ca. 3 sec de Model/Off knop ingedrukt te houden.
- De stoelverwarmer wordt ingeschakeld in de laagste stand (1).
- Druk meermaals op de Model/Off knop om van instelling te wisselen.
- De stoelverwarmer heeft 8 standen. In het scherm ziet u welke stand is ingesteld : 1 t/m 8
- Deze 8 standen staan voor een oppervlakte temperatuur van de stoelverwarmer:
  - Laag :               Stand 1-3: 33-43 °C \*
  - Midden :           Stand 4-6: 45-55 °C \*
  - Hoog:               Stand 7-8: 60-65 °C \*
- Zolang de stoelverwarmer opwarmt knippert de ingestelde stand (1-8). Als de stoelverwarmer de gewenste temperatuur heeft bereikt stopt het cijfer met knipperen.

*\*De gerealiseerde temperatuur is afhankelijk van de omgevingstemperatuur.*

### Timer instellingen

*Let op; wanneer de stoelverwarmer wordt ingeschakeld start de timer automatisch op 90 min. De stoelverwarmer schakelt dus altijd automatisch uit na 90 min, tenzij de timer anders wordt ingesteld.*

- Om de timer in te stellen, houdt de TIMER knop ingedrukt tot de minuten gaan knipperen
- Druk meermaals op de timer knop om de gewenste instelling te kiezen
- Het scherm toont het overgebleven aantal minuten op de timer.
- De timer kan worden ingesteld op: 30 / 60 / 90 / 120 / 180 / 240 en 300 minuten.

## Ondersteuning

---

Neem voor ondersteuning contact op met uw verkooppunt of installateur. Of voor Nederland/België met de importeur:

**DVH products** / [service@dvh-products.nl](mailto:service@dvh-products.nl) / +31 (0) 33 – 303 4337





EN

## VH Chair heater “Vulcano”

Thank you for purchasing the Vulcano chair heater. This chair heater is especially designed to give a comfortable warmth to your back and the seat of the chair. The chair heater can be used on a chair, at a desk or in any spot where a bit of extra warmth and comfort is necessary. The heater has 8 different heating settings which are controlled by the LCD controller. In addition, a timer can be activated to ensure that the chair heater is switched off automatically.

### Specifications

- Carpet chair heater
- Color: black or apricot
- Works with 230 V, equipped with on/off switch, 8 heating settings and automatic timer
- Cable length: 3 meters *1 m. to the controller, 2 m. from controller to plug*
- Anti-slip bottom
- Overheating protection
- Eight (8) heating settings. Maximal temperature:
  - o Low : Settings 1-3: 33-43 °C \*
  - o Middle : Settings 4-6: 45-55 °C \*
  - o High: Settings 7-8: 60-65 °C \*

*\*The actual achieved temperature depends on the ambient temperature.*

### Available sizes

| Artikelcode | Afmeting    | Maximaal vermogen | Gemiddeld verbruik | Kleur   |
|-------------|-------------|-------------------|--------------------|---------|
| VH-SV101    | 40 x 120 cm | 100 Watt          | 55 Watt            | Black   |
| VH-SV102    |             |                   |                    | Apricot |

### Application

- The chair heater may only be used in dry areas.
- The chair heater can only be used on non-heat sensitive materials. Pay attention when using the chair heater on PVC or vinyl furniture.
- The chair heater cannot be used on untreated wood (such as underlayment, for example). Stains may occur when used on such untreated surfaces.



## Instructions for use

---

- Do not use in wet / humid areas or outdoor environments.
- Do not cover the chair heater. This is to prevent overloading and overheating. Only use the chair heater on a dry and flat surface.
- Do not bend, pierce, or cut the chair heater.
- Ensure that the connection cable and related parts and components are not damaged.
- In case of damage to the cable, switch off the chair heater and immediately remove the plug from the socket, contact your supplier if necessary.
- Only clean the carpet with a damp cloth and mild detergent. Do not submerge in water. The outer cover can be machine washed. See further instructions.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are under supervision, or have been given sufficient instructions regarding the use of the appliance by a person responsible for their safety.

## Important safety information

---

- Always switch off the power mains completely when handling the electrical components, during installation, removal, cleaning or maintenance.
- Read all information in this manual carefully.
- Only use the chair heater as described in the manual.

## Warranty

---

Full warranty applies if the chair heater is installed correctly and used in accordance with these instructions. The chair heater is a maintenance-free heating system with a 2-year warranty on the electrical operation of the chair heater.

## Maintenance and cleaning

---

The outer cover can be cleaned by hand or in the washing machine.

- Turn off the chair heater and remove the plug from the socket.
- Unplug the wires from the chair heater at the connection point. The plug and power cord cannot come into contact with water.
- Wash the chair heater at low temperature (max. 30 °C) by hand or on a gentle cycle in the washing machine. Use a mild detergent.  
Please note: Do not iron, do not tumble dry, do not dry clean and do not bleach.
- Do not clean the power cord and plug.



## Using the chair heater

---

### Temperature settings

To switch on: press and hold Model/OFF button for about 3 sec.

The chair heater starts operation on the lowest setting (1)

Press the Model/off button to switch between the heating settings (1-8) The display will display the current setting.

The eight different temperature settings represent the surface temperature of the carpet:

- Low :                Settings 1-3: 33-43 °C \*
- Middle :           Settings 4-6: 45-55 °C \*
- High:               Settings 7-8: 60-65 °C \*

*\*The actual achieved temperature depends on the ambient temperature.*

As long as the chair heater is heating up, the set position (1-8) flashes. When the chair heater has reached the desired temperature, the number stops flashing.

### Timer settings`

*NB; when the chair heater is switched on, the timer automatically starts at 90 min. The chair heater therefore always switches off automatically after 90 min unless the timer is set differently.*

- To set the timer, press and hold the TIMER button until the minutes start flashing
- Press the timer button several times to select the desired timer. On the display the number of minutes left on the timer is shown.
- The timer can be set to: 30 / 60 / 90 / 120 / 180 / 240 and 300 minutes.

## Support

---

**For support, please contact your installer or vendor. Or for The Netherlands/Belgium contact the importer:**

**DVH products / [service@dvh-products.nl](mailto:service@dvh-products.nl) / +31 (0) 33 – 303 4337**

